

## Plotter Set up for A Plotter not listed in Omega

- Click Start
- Click Run
- Type “device.ini” and click ok
- Notepad will launch
- Scroll down to the HPGLtemp line (approximately 5 clicks in the scroll bar)
- The line will look like this
- **HPGLTEMP=9999,1.016,0,13.00,59,3,1.0,1.0,com2:**
- Highlight the entire line, right click and copy
- Click at the end of the HPGL....line to unselect it
- Press “Enter” to create an open line below it. In that space, right click and select paste (this will insert a copy of the HPGLTEMP line)
- Click across the 13.00 and type the width of the cutting area on the plotter.
- Click across the HPGLTEMP and type actual plotter name
- At the top click file and save
- When installing in Omega that plotter will now be available