

## **How the Roland Color Library should be installed in CorelDraw**

Roland VersaWorks 2.2 provides the Roland Color Library files for CorelDraw in C:\Program Files\Roland VersaWorks\Swatch\CorelDraw folder. The library file must be copied into the folder used by CorelDraw to store the user defined spot colors. Each version of CorelDraw may store the swatch library files in a slightly different folder. For CorelDraw 12 and later (up to X3) running on Windows XP, the user defined spot color library file is stored in "C:\Documents and Settings\user\_name\Application Data\Corel\Graphics12 (or 13)\User Custom Data\Palettes" folder. Copy the file "userinks.cpl" to the Palettes folder and then the library will be available for selection the next time you start CorelDraw. Note that the "Application Data" folder is a hidden folder and it **will** not be visible unless you enable Explorer to display hidden files and folders. Please be aware that you are overwriting an existing file and it is recommended to back up the original userinks.cpl file in case you have created custom spot colors prior to this.

Older versions of Corel may store the userinks.cpl file under the CorelDraw installation folder.